





- Place the spacer between the axle carrier and the car body
- After installation adjust the front axle!